

FLOODLIGHTS



IMPORTANT: Floodlights MUST be off by 10pm

When you first switch on the floodlights, the floodlights will all come on at PATHFINDER level (10%).

In the corner of Court One (under the protective hood) is the BUTTON BOX:

When you get down to the courts, you can choose your lighting level.

For casual play, coaching and club evenings, you'll probably find that TRAINING (70%) is a comfortable level.

However, on some occasions (matches perhaps) you may wish to choose FULL (100%) .

Press the relevant button just once. No need to hold it in. After approximately five seconds the lights will react.

When you're only using one court, or taking a breather, you can take the lights down to PATHFINDER level to save energy.

LED lights do not require a warm-up or cool-down period. You can adjust the levels as often as you like.



IMPORTANT: Floodlights MUST be off by 10pm